



Content of delivery: 1x Heating Element IN-4010/11, 1x Quick Installation Guide

INSTAR Deutschland GmbH hereby ensures that you will not lose your warranty by installing this additional heater.


ATTENTION: Any damages caused by the user by faulty installation are excluded of the warranty.



Step 1: Remove the glass dome by turning it counter-clockwise.



Step 2: Remove the 4 screws (marked on the right photos) that are holding the camera inside the casing.



Step 3: Carefully remove the camera from its casing to reach the connectors underneath on the mainboard.



Step 4: Regarding the mainboard there are two free connectors. Please connect the cable coming from the heating element to the connector on the left side labeled with 12V (see marker labeled with 1). The second connector cable of the heating element stays unplugged (see marker labeled with 2). Subsequently place the heating element underneath the mainboard with the thermostat facing the black mounting plate. Now reassemble the camera.

